

# INSTALLATION GUIDE

HVS-49SSD240G

HVS-490 SSD Option

1<sup>st</sup> Edition

# 1. Upon Receipt

The HVS-49SSD240G is an SSD expansion option that stores stills and clips for the HVS-490, with an available resume function.

Check your received items against the packing list below. Check to ensure no damage has occurred during shipment. If damage has occurred, or items are missing, inform your supplier immediately.

# HVS-49SSD204G Box

ITEM	QTY	REMARKS
HVS-49SSD240G	1	SSD
Shield	1	With 4 binding screws
Panel	1	With screws
Installation guide	1	This guide



SSD installation should only be performed by qualified technical personnel. Before installing the SSD, turn the HVS-490 power OFF and unplug the power cables.

# 2. HVS-49SSD240G Installation

- 1. Turn off HVS-490 and unplug the power cable.
- 2. Unfasten the two screws on both ends of the slot shown as below and uninstall the board.



3. Remove the two screws from the blank panel installed on the detached board as shown below.



4. Attach the shield panel with the four supplied binding screws as shown below.




5. Press the blue button in front of the HVS-49SSD240G to open the handle as shown in the below figure.



6. Slide the HVS-49SSD240G into the shield panel slot as shown.



7. Push to close the HVS-49SSD240G cover handle. Doing so secures the HVS-49SSD240G into the slot.



8. Attach and fasten the supplied panel with the two screws. Make sure the panel is facing the correct direction and covers the HVS-49SD240G slot entirely.



9. Return the board from Step 2 above to the HVS-490 rear panel by sliding guide rails onto the back, then fastening the screws onto both ends.

# 3. Menu Confirmation

Verify that the HVS-49SSD240G is correctly recognized on the menu.

- (1) Connect the AC cable and turn **On** the power switch.
- (2) On the control panel menu screen, tap the **STATUS** tab and **OPTION** button in order, then open the **[STATUS>OPTION]** menu.
- (3) Verify the HVS-49SSD has been INSTALLED and is displayed. (See figure below.)





#### **FOR-A COMPANY LIMITED**

Head Office 3-8-1 Ebisu, Shibuya-ku, Tokyo 150-0013, Japan
Overseas Division Tel: +81(0)3-3446-3936 Fax: +81(0)3-3445-5116

Japan Branch Offices Osaka/Okinawa/Fukuoka/Hiroshima/Nagoya/Sendai/Sapporo

R&D/Production Sakura Center/Sapporo Center

## FOR-A Corporation of America Corporate Office/Service Center

11155 Knott Ave., Suite G, H & I, Cypress, CA 90630, U.S.A.

Tel: +1 714-894-3311 Fax: +1 714-894-5399

# FOR-A Corporation of America Northeast Office

1360 Clifton Ave., Clifton, NJ 07012, U.S.A. Tel: +1 973-220-8471 Fax: +1 714-894-5399

# **FOR-A Corporation of America Southeast Office**

Tel: +1-305-773-7608

# **FOR-A Corporation of America Support Center**

2400 N.E. Waldo Road, Gainesville, FL 32609, U.S.A. Tel: +1 352-371-1505 Fax: +1 714-894-5399

#### FOR-A Latin America and the Caribbean Miami Office

Tel: +1 657-600-5759

# FOR-A Latin America and the Caribbean Sao Paulo Office

Tel: +55 (0)11-99913-3751

#### FOR-A Europe S.r.l.

Via Volturno, 37, 20861 Brugherio MB, Italy
Tel: +39 039-916-4811 Fax: +39 039-878-140

#### **FOR A UK Limited**

Trident Court, 1 Oakcroft Road Chessington, KT9 1BD, U.K. Tel: +44 (0)20-3044-2935 Fax: +44 (0)20-3044-2936

#### FOR-A Italia S.r.I.

Via Volturno, 37, 20861 Brugherio MB, Italy Tel: +39 039-881-086/103 Fax: +39 039-878-140

#### **FOR-A Corporation of Korea**

1007, 57-5, Yangsan-ro, Yeongdeungpo-gu, Seoul 07271, Korea Tel: +82 (0)2-2637-0761 Fax: +82 (0)2-2637-0760

#### **FOR-A China Limited**

1618 Huateng Building, No. 302, 3 District, Jinsong, Chaoyang, Beijing 100021, China Tel: +86 (0)10-8721-6023 Fax: +86 (0)10-8721-6033

## **FOR-A Middle East Africa Office**

Aurora Tower, Office 1407, Dubai Media City, P.O. Box 502688, Dubai, UAE Tel: +971 (0)4 551 5830 Fax: +971 (0)4 551 5832

# FOR-A India Private Limited. Mumbai Office

2nd Floor, Valecha Chambers, Link Road, Andheri (W), Mumbai 400053, India Tel: +91-(0)22-2673-3623 Fax: +91-(0)22-2639-3415

#### FOR-A India Private Limited. Delhi Office

8th floor, World Trade Tower, Sector-16, Noida, Uttar Pradesh 201301, India Tel: +91-(0)12-0423-8674

## **FOR-A South East Asia Office**

Studio 09, Rm. A1, 3/F., Phase 1, Hang Fung Ind. Bldg., 2G Hok Yuen St., Hung Hom, Hong Kong Tel: +852 2110-1352